



Step 1.1 Install Base Trim up against Endwall Structure. (use other appropriate trim when conditions and wall panels warrant)

Step 1.2 Install Membrane Strip over Base Trim.

Step 2.1 Install J Channel and Angle Trim at Endwall Condition. (use other appropriate trim when conditions and wall panels warrant)

Step 2.2 Install Membrane Strip over J Channel and Angle Trim.

Step 3.1 Install Wall Panels.



ATAS INTERNATIONAL, INC
 Allentown PA
 610-395-8445
 Mesa AZ
 480-558-7210

TITLE
Base to Endwall Solid Substrate Detail

REV. NO.	DATE	DESCRIPTION OF REVISION	BY	APP	DWG. NO.	DR	DATE
						KRK	3/31/2015
					MATERIAL	APP	DATE
					SH. SIZE	B	SCALE
							X:X