







**Step 1.1** Run Underlayment on Substrate and return into Window opening.

**Step 1.2** Install Jamb Angle Trim. (field notch so leg against wall runs long)

**Step 2.1** Install Window Sill J Channel with appropriate Fasteners.

**Step 2.2** Install Jamb J Channel just below Window Sill J Channel and on top of Butyl Tape with Angle Trim for color.

**Step 2.3** Strip in J Channel with Membrane to create a positive flow over trim.

**Step 3.1** Install Window Sill Trim onto Window Sill J Channel.

**Step 4.1** Install Wall Panels.

**Step 4.2** Field trim panels to fit around trim. (use other appropriate trim when conditions warrant)

**Step 5.1** When windows are installed use Backer Rod and Sealant between Window Frame and Trim.



					Jamb to Window Sill Solid Substrate Detail
					DWG. NO.  DR  KRK  A/14/201
					MATERIAL APP DATE
REV. NO.	DATE	DESCRIPTION OF REVISION	BY	APP	SH. SIZE B SCALE X:X

