



Outside Corner Extrusion

SterraCore Panel

Note: Spacing between Panels and Water and Air Resistive Barrier are shown for Clarity.

(1) Outside Corner Extrusion installed on Foam Tape. 2" min. gap at 24" O.C. and at transition to vertical moldings.

(2) Panel Adhesive applied 24" O.C. Horizontally and 16" O.C. Vertically.

(3) Foam Tape installed Vertically in between Panel Adhesive.

ATAS ATAS INTERNATIONAL, INC
 Allentown PA
 610-395-8445
 Mesa AZ
 480-558-7210

TITLE
SterraCore Outside Corner Detail - 1 Piece

DR	KRK	DATE	8/4/2015
APP	JEB	DATE	8/26/2015
SH. SIZE	B	SCALE	X:X

REV. NO.	DATE	DESCRIPTION OF REVISION	BY	APP