



**Step 1.1** Run Underlayment on Substrate and return into Window opening.

**Step 2.1** Install Angle Trim for the Jamb Condition.  
**Step 2.2** Install Jamb Angle Trim for Head Condition.

**Step 3.1** Install J Channel just below horizontal leg of Head Trim (will be installed during step 4) and on top of Butyl Tape with Angle Trim for color.

**Step 4.1** Install Head Trim on Jamb Trim.  
**Step 4.2** Field Notch Head Trim down into J Channel. Head Trim should overlap J Channel as shown.

**Step 5.1** Strip in Head Trim and J Channel with Membrane to create a positive flow over trim.

**Step 6.1** Install Wall Panels.  
**Step 6.2** Field trim panels to fit around trim. (use other appropriate trim when conditions warrant)

**Step 7.1** When windows are installed use Backer Rod and Sealant between Window Frame and Trim.

**ATAS** ATAS INTERNATIONAL, INC  
 Allentown PA  
 610-395-8445  
 Mesa AZ  
 480-558-7210

TITLE  
**Head to Jamb Solid Substrate Detail**

REV. NO.	DATE	DESCRIPTION OF REVISION	BY	APP	DWG. NO.	DR	DATE
						KRK	4/7/2015
					MATERIAL	APP	DATE
					SH. SIZE	B	SCALE
							X:X