



Step 1.1 Install Standing Seam Panels on Roof Deck. (see eave detail for installation at eave trim)

Step 2.1 Install Z Closures at Hip Condition on top of Standing Seam Panels with appropriate accessories.

Step 3.1 Field Notch and Fold Hip Cap so that it can be folded under Eave Trim. (leave gap to let water drain)

Step 3.2 Install Hip Cap on Z Closures.



ATAS INTERNATIONAL, INC
 Allentown PA
 610-395-8445
 Mesa AZ
 480-558-7210

TITLE Standing Seam Hip at Eave Detail

REV. NO.	DATE	DESCRIPTION OF REVISION	BY	APP	DWG. NO.	DR	KRK	DATE	2/17/2015
						APP		DATE	
					MATERIAL	SH. SIZE	B	SCALE	X:X