


Step 2.1: Fasten Support Z in the Appropriate Area. **Step 2.2:** Lightly abrade the surface that will recieve the VHB Tape[™] using a 3M[™] Scotch-Brite[®] Hand Pads (7447 Maroon) Step 2.3: Support Z Surface Should be Cleaned Using the Following Preporation Methods:

IPA/Water: Clean Surface with a 50:50 Mixture of Isopropyl Alcohol (IPA) and Water.

3M Adhesion Promoter 111 (AP111): Clean Surface with 50:50 IPA/Water Mixture Followed by Priming Surface with (AP111) Solution. Primer is Applied with a Clean Wetted Cloth and Allowed to Dry/ Evaporate Prior to Applying VHB Tape.

3M Primer 94 (P94): Clean Surface with 50:50 IPA/Water Mixture Followed by Priming Surface with (P94). Solution is Applied Wet and Allowed to Dry Without Wiping.



01	10/3/2022	Updated Step 2 to Inc
REV. NO.	DATE	DESCRIPTION O

Page 1 of 2

